


# 2ch Current Loop Supply (with Indication Function)

Model : **SE2D**

### Model



### How to Order

Specify a model. (e.g.) SE2D-1-0

#### Factory Default Value:

CH1 input	4 to 20mA DC
CH2 input	4 to 20mA DC
CH1 output	4 to 20mA DC
CH2 output	4 to 20mA DC

### Accessories (Sold Separately)

Communication cable to connect console software: CMB-001

### Input Specifications


DC Current	
Input range	Shunt resistor
4 to 20mA DC	50Ω built-in

### Output Specifications

When the output range lower limit is zero, (even if zero adjustment results in a negative value), the output value will not be negative.

DC Current			
Output range	Allowable load resistance	Zero adjustment range	Span adjustment range
4 to 20mA DC	700Ω or less	-5 to 5%	95 to 105%
0 to 20mA DC	700Ω or less	0 to 5%	95 to 105%
0 to 12mA DC	1.2kΩ or less	0 to 5%	95 to 105%
0 to 10mA DC	1.2kΩ or less	0 to 5%	95 to 105%
1 to 5mA DC	2.4kΩ or less	-5 to 5%	95 to 105%

DC Voltage			
Output range	Allowable load resistance	Zero adjustment range	Span adjustment range
0 to 1V DC	100Ω or more	0 to 5%	95 to 105%
0 to 5V DC	500Ω or more	0 to 5%	95 to 105%
1 to 5V DC	500Ω or more	-5 to 5%	95 to 105%
0 to 10V DC	1kΩ or more	0 to 5%	95 to 105%



### Power for 2-wire Transmitter

Output voltage: 24 to 28V DC (When load current is 20mA)  
 Ripple voltage: Within 200mV DC (When load current is 20mA)  
 Max. load current: 25mA DC

### Performance

Basic accuracy (at 23°C of ambient temperature)

- Input: Within ±0.1%
- Output: Within ±0.1%

Indication accuracy: Within Basic accuracy ±1 digit

Input sampling period: 25ms, 125ms, 250ms (Selectable by the keypad)

Response time: (Selectable by the keypad)

- 65ms (typ.) (0→90%) (Input sampling period: 25ms)
- 225ms (typ.) (0→90%) (Input sampling period: 125ms)
- 425ms (typ.) (0→90%) (Input sampling period: 250ms)

Temperature coefficient: ±0.015%/°C or less

Insulation resistance: 10MΩ or more, at 500V DC (Input - Output - Power)

Dielectric strength: 2.0kV AC for 1 minute (Input - Output - Power)

### General Structure

Case: Flame-resistant resin Color: Light gray

Front panel: Membrane sheet

Setting : Using front keypad

Connector for console software: Only CMB-001 cable usable


Displays and indicators:

Input display: 7-segment Red LED display 4-digit, Character size: 10 x 4.6mm (H x W)

Output display: 7-segment Red LED display 4-digit, Character size: 10 x 4.6mm (H x W)

Power indicator: Green LED

CH1, CH2 indicators: Yellow LED



## ■ Installation Specifications

- Power supply: 100 to 240V AC 50/60Hz  
24V AC/DC 50/60Hz
- Allowable voltage range: 85 to 264V AC, 20 to 28V AC/DC
- Power consumption: Approx. 8VA
- Ambient temperature: -5 to 55°C
- Ambient humidity: 35 to 85%RH (non-condensing)
- Mounting: DIN rail
- Dimensions: W30 x H88 x D108mm (including socket)
- Weight: Approx. 190g (including socket)

## ■ Attached Functions

- Light sensor: Automatically measures and controls brightness of the displays, saving energy.
- Power failure countermeasure:  
The data is backed up in non-volatile IC memory.
- Self diagnosis: The CPU is monitored by a watchdog timer, and when an abnormal status is found on the CPU, the unit is switched to warm-up status turning all outputs OFF.

## ■ Environmental Specification

RoHS directive compliance

## ■ Settings

### Function Keys


- UP Key: Increases numeric value.
- DOWN Key: Decreases numeric value.
- MODE Key: Selects a setting mode.
- SUB-MODE Key: Lights the displays again when in unlit status. (The UP, DOWN or MODE Key also lights the displays again when in unlit status.)

## ■ Displays and Indicators


- Input display: Indicates the input value.
  - Indication of -2000 or less: The minus (-) sign and input value light alternately.
  - Indication of 10000 or more: The lower 4 digits flash.
- Under range: "—" flashes on the Input display.
- Over range: "—" flashes on the Input display.
- Warm-up indication:  
For approx. 3 seconds after the power to the instrument is turned on, CH1 input type is indicated on the Input display, and CH2 input type is indicated on the Output display.
- Output display: Indicates the output volume in percentage (%) form.
- Power indicator: A green LED is lit when the power to the instrument is turned on.
- CH1 indicator: A yellow LED is lit when CH1 is selected during [Display selection].
- CH2 indicator: A yellow LED is lit when CH2 is selected during [Display selection].

## ■ Solderless Terminals


### Y Terminal




### Ring Terminal




## ■ Circuit Configuration, Terminal Arrangement



### When used as a Current Loop Supply



### When used as an Isolator



## ■ External Dimensions (Scale: mm)

